

Simple Reclaimed Wood Paneling Installation

This is a solid reclaimed wood paneling in 3" and 4" widths and random lengths.

You will install all 3" boards in the same line and all 4" boards on the same line. Do not try to mix 3" and 4" boards on the same line or it will leave 1" gaps you will need to fill in.

You will want to use the following items for installation:

- Level
 - Glue (flooring mastic with trowel or liquid nails, etc.)
 - Staples or finish nails.
 - Circular saw or table saw to cut length of each row and width of final pieces.
1. Make sure you use a level and mark a working line on the first row (typically on the floor). Most floors, walls and ceilings are NOT perfectly square or level so always lay your first row on a level line.
 2. Either apply a flooring mastic to the back of the paneling (the clear face) or apply liquid nails to the back of the paneling and apply along the level line.
 3. Use a finish nail or staple (staple or nail gun are best but not necessary) to hold the boards in place once applied to your wall.
 4. Always finish 1 row before moving on the next level above it. Working on more than 1 row at a time can create leveling problems.
 5. Work your way from bottom to top.
 6. Trim piece as you get to the end of each row so you have the right fit.
 7. Once you reach the top, you will want to trim the last row so it fits well within the final space available.
 8. When done, leave as-is or apply a finish of your choice.