

Reclaimed Wood Crate Assembly

Set Includes



2 End Pieces



2 Side Pieces



1 Bottom



Screws



1) Use 2 Small Screws to screw Side Panel to End Panel as shown.



2) Use 2 Small Screws to screw one more Side Panel to End Panel as shown.




3) Use 4 Small Screws to Screw in The final Side Panel to connect all 4 sides



4) Your Crate should look like above



5) Turn over and place the Bottom with the flat surface facing down



6) Set the bottom into the crate so it's flat. You may have to adjust the sides to achieve this.



7) Use 4 Large screws to screw the bottom into the sides as shown



8) Voila! You Did it!